LWM2M
Client
Observe, Cancel Observation
Notify
LWM2M
Server